

### Warning:

- This tricycle is suitable for 18-36 months old children.
- Must be used under adult's supervision only.
- Do not ride on slope and bumpy surface. Not to be used on streets.
- Do not ride during rain, strong wind or snowing weather.
- Please make sure all the screws are tightened when assembling.
- Please dispose the plastic bags soon after you open the package, Keep away from children to avoid danger of asphyxia.

**Imported & Marketed By**  
Brainbees Solutions Pvt. Ltd.  
Corporate & Registered Office Address:  
Rajashree Business Park, Plot No: 114,  
Survey No. 338, Tadiwala Road,  
Near Sohrab Hall, Pune 411 001

**Customer Care :**  
☎ 020-46608179  
✉ [customercare@brainbees.com](mailto:customercare@brainbees.com)

**Customer Care Address:**  
Same as Importer's address

Made in China

18 to 36  
Months

Carrying Capacity  
up to 25 kg

User's Manual

Babyhug Paramount Tricycle

Style Code : B6TB002



**babyhug®**

**baby tricycle**

■ Light & Music

■ Large Front Wheel

■ Strong & Sturdy Frame

Please read the instruction manual thoroughly before using the products and keep for future reference

## Installation



Picture 1

1. Insert the axle through the frame (rear wheel), and place the black cover on each side. Then place the rear wheels and fasten the screws securely on each side. See Picture 2



Picture 2

2. Insert the front fork with wheel into the frame. See picture 3



Picture 3

3. Place the handle bar to the front fork as shown in Picture 4 and fasten the screws. Make sure the handle direction is straight before tightening the screws.



Picture 4

4. Place the seat on the frame. Make sure the holes on the seat are aligned to that of the frame and fasten the screws securely. See Picture 5



Picture 5

5. Place the basket on the frame. Make sure the holes on the basket are aligned to that of the frame and fasten the screws securely. See Picture 6



Picture 6